CRANE SAFETY: OPERATION What Would Cosmo Do?







Operation Precautions

When operating a crane, be familiar with the following precautions:

- Maintain firm footing or be otherwise secured
- Check brake function by tensioning the hoist prior to use
- Use hook latches

- Make sure hook latches are closed
- 8
- Avoid swinging the load or hook

- Inspect the hoist regularly
- Lubricate the hoist load per manufacturer recommended
- Do not operate except with manual power
- Do not allow your attention to divert

<u>Operators</u>

Cranes and hoists will only be operated by trained operators.

- No individual under age 18 may operate a crane or hoist at BYU.
- Cranes will only be operated under normal operating conditions as defined by the manufacturer.
- Perform a Pre-Use inspection prior to each use.

<u>Critical Lifts</u>

Critical lifts require special considerations to ensure worker safety, including:



- The weight of the hoisted load approaches the crane's maximum capacity.
 Two or more cranes simultaneously lift the same load.
- Personnel are being hoisted.

Before a critical lift is performed, the responsible person must review a written safety plan with all individual who will be involved in the lift.

The risk among crane operators is significant, corresponding to a risk of more than one death per thousand workers over a working lifetime of 45 years.

https://www.osha.gov/archive/oshinfo/priorities/crane.html





Risk Management and Safety

RMB|801-422-4468

